

# COMPONENT NUMBER CODE CHARTS v.1


Use the following charts to calculate component values for number coded resistors, capacitors and inductors. The charts included are for 3- and 4-digit chip resistors; chip resistor decimals and symbols; numbered resistors with tolerance letter codes; E96 series, 0603 resistors; 3-digit capacitors; 2-digit alphanumeric chip capacitors; 3-digit inductors; and capacitor and inductor decimals.

These charts can be used for the *exercises* in DVD-165C, for the *Review Questions* and for the IPC *Training Certification* Exam.



 $2,500\Omega + 1\%$ 

## **3-DIGIT CHIP RESISTOR NUMBER CODE CHART**



# 3-DIGIT VALUE CODE ± 5% Tolerance

1st and 2nd numbers SIGNIFICANT VALUE	3rd number MULTIPLIER (number of zeros)
Use as is in the order written	0 = no zeros 1 = add 1 zero 2 = add 2 zeros 3 = add 3 zeros 4 = add 4 zeros 5 = add 5 zeros 6 = add 6 zeros 7 = add 7 zeros 8 = add 8 zeros 9 = add 9 zeros

Resistors are measured in "ohms." The symbol for ohms is  $\Omega$ . You may also see the value of a resistor expressed as "K" ohms or "M" ohms. K stands for Kiloohms or one thousand ohms, and M stands for Meg-ohms or one million ohms.

Therefore: a 10,000 ohm resistor can be abbreviated as 10K for 10 Kilo-ohms. In the same manner a 6,000,000 ohm resistor can be abbreviated as 6M, for 6 Meg-ohms.

Equivalents: 1,000,000 ohms = 1,000 K-ohms = 1 M-oh

#### 4-DIGIT CHIP RESISTOR NUMBER CODE CHART



## 4-DIGIT VALUE CODE + 1% Tolerance

1st, 2nd and 3rd numbers SIGNIFICANT VALUE	4th number MULTIPLIER (number of zeros)
Use as is in the order written	0 = no zeros 1 = add 1 zero 2 = add 2 zeros 3 = add 3 zeros 4 = add 4 zeros 5 = add 5 zeros 6 = add 6 zeros 7 = add 7 zeros 8 = add 8 zeros 9 = add 9 zeros

Resistors are measured in "ohms." The symbol for ohms is  $\Omega$ . You may also see the value of a resistor expressed as "K" ohms or "M" ohms. K stands for Kiloohms or one thousand ohms, and M stands for Meg-ohms or one million ohms.


Therefore: a 100,000 ohm resistor can be abbreviated as 100K for 100 Kilo-ohms. In the same manner a 6,000,000 ohm resistor can be abbreviated as 6M, for 6 Meg-ohms.

Equivalents: 1,000,000 ohms = 1,000K-ohms = 1M-ohm.


## DECIMALS AND SYMBOLS FOR 3- AND 4-DIGIT RESISTORS



When the letter R is used as part of a 3- or 4-digit number code, it indicates the position of a decimal point. For example, a 3-digit code of 4R3 would be decoded as 4.3  $\Omega$ . If the code is R43, the value would be .43  $\Omega$ . And a 4-digit number code of 65R5 would be decoded as 65.5  $\Omega$ . When a letter code is used to indicate a decimal point, there is no multiplier.



The letter K also indicates the position of a decimal point in 3- and 4-digit number codes. The difference is that the value will be measured in kilo-ohms. For example, 8K9 would be 8.9K  $\Omega$ . When a letter code is used to indicate a decimal point, there is no multiplier.



Decimal points can also be indicated by the letters M and L. M is used when the value is measured in meg-ohms and L is used when the value will be measured in milli-ohms. When a letter code is used to indicate a decimal point, there is no multiplier.



Some number codes use the *colon* symbol, or two small boxes to represent the number 8. For example, the 3-character code:53 equals 853. The two value numbers are 85. The multiplier is 3 – so three zeros added after 85 gives the value 85,000  $\Omega$ , or 85K  $\Omega$ . As long as there is no letter indicating a decimal point, 3- and 4-character codes containing a colon symbol are calculated the same as 3- and 4-digit number codes.

#### **AXIAL RESISTOR VALUE AND TOLERANCE CODES**



 $6M\Omega + 1\%$ 

1st, 2nd and 3rd numbers SIGNIFICANT VALUE	4th number MULTIPLIER: (number of zeros)		RANCE code
Use as is in the order written	0 = add no zeros 1 = add 1 zero 2 = add 2 zeros 3 = add 3 zeros 4 = add 4 zeros 5 = add 5 zeros 6 = add 6 zeros 7 = add 7 zeros 8 = add 8 zeros 9 = add 9 zeros	ABCDFGHJKLM	±.05% ±.1% ±.25% ±.5% ±1% ±2% ±3% ±5% ±10% ±15% ±20%

Resistors are measured in "ohms." The symbol for ohms is  $\Omega$ . You may also see the value of a resistor expressed as "K" ohms or "M" ohms. K stands for Kiloohms or one thousand ohms, and M stands for Meg-ohms or one million ohms.

Therefore: a 100,000 ohm resistor can be abbreviated as 100K for 100 Kilo-ohms. In the same manner a 6,000,000 ohm resistor can be abbreviated as 6M, for 6 Meg-ohms.

These axial resistors typically have a single letter code to the right of the number code to indicate tolerance.

Equivalents: 1,000,000 ohms = 1,000K-ohms = 1M-ohm.

# E96 SERIES, 0603, ± 1% CHIP RESISTORS



 $340\Omega \pm 1\%$ 


## **E96 Value Code Chart**

# 1%	# 1%	# 1%	# 1%	# 1%	# 1%
01 10.0	17 14.7	33 21.5	49 31.6	65 46.4	81 68.1
02 10.2	18 15.0	34 22.1	50 32.4	66 47.5	82 69.8
03 10.5	19 15.4	35 22.6	51 33.2	67 48.7	83 71.5
04 10.7	20 15.8	36 23.2	52 34.0	68 49.9	84 73.2
05 11.0	21 16.2	37 23.7	53 34.8	69 51.1	85 75.0
06 11.3	22 16.5	38 24.3	54 35.7	70 52.3	86 76.8
07 11.5	23 16.9	39 24.9	55 36.5	71 53.6	87 78.7
08 11.8	24 17.4	40 25.5	56 37.4	72 54.9	88 80.6
09 12.1	25 17.8	41 26.1	57 38.3	73 56.2	89 82.5
10 12.4	26 18.2	42 26.7	58 39.2	74 57.6	90 84.5
11 12.7	27 18.7	43 27.4	59 40.2	75 59.0	91 86.6
12 13.0	28 19.1	44 28.0	60 41.2	76 60.4	92 88.7
13 13.3	29 19.6	45 28.7	61 42.2	77 61.9	93 90.9
14 13.7	30 20.0	46 29.4	62 43.2	78 63.4	94 93.1
15 14.0	31 20.5	47 30.1	63 44.2	79 64.9	95 95.3
16 14.3	32 21.0	48 30.9	64 45.3	80 66.5	96 97.6

# **Multiplier Chart**

Letter Code	Explanation		
Y X	Add no zeros, move decimal 1 place to the left		
A	Leave number as is  Add 1 zero, move decimal 1 place to the right		
B C	Add 2 zeros, move decimal 2 places to the right Add 3 zeros, move decimal 3 places to the right		
D E	Add 4 zeros, move decimal 4 places to the right Add 5 zeros, move decimal 5 places to the right		
F	Add 6 zeros, move decimal 6 places to the right		

#### CAPACITOR VALUE AND TOLERANCE CHART



47,000,000pF or 47μF, 10V, ± 10%

1st and 2nd numbers SIGNIFICANT VALUE	3rd number MULTIPLIER: (number of zeros)	TOLERANCE letter code
Use as is in the order written	0 = add no zeros 1 = add 1 zero 2 = add 2 zeros 3 = add 3 zeros 4 = add 4 zeros 5 = add 5 zeros 6 = add 6 zeros 7 = add 7 zeros 8 = add 8 zeros 9 = add 9 zeros	A ±.05% B ±.1% C ±.25% D ±.5% F ±1% G ±2% H ±3% J ±5% K ±10% L ±15% M ±20%

Capacitors are measured in "farads." There are picofarads (pF), nanofarads (nF), and microfarads ( $\mu$ F).

3-digit capacitors are always calculated in picofarads – the smallest unit of measurement.

Tolerance is typically indicated by a letter code. When tolerance is not specified, it is assumed to be  $\pm$  20%.

Equivalents: 1,000,000pF (picofarads) = 1,000nF (nanofarads) =  $1\mu$ F (microfarad)

## 2-DIGIT ALPHANUMERIC CHIP CAPACITOR CHART



1,800pF + 20%

#### **Chip Capacitor Letter Values**

LETTER	EQUALS	LETTER	EQUALS	LETTER	EQUALS
Α	1.0	М	3.0	Υ	8.2
В	1.1	N	3.3	z	9.1
С	1.2	Р	3.6	а	2.5
D	1.3	Q	3.9	b	3.5
E	1.5	R	4.3	d	4.0
F	1.6	S	4.7	е	4.5
G	1.8	Т	5.1	f	5.0
н	2.0	U	5.6	m	6.0
J	2.2	V	6.2	n	7.0
ĸ	2.4	w	6.8	t	8.0
L	2.7	х	7.5	у	9.0

**Chip Capacitor Multiplier Chart** 

Number	Explanation		
0	Leave number as is		
1	Add 1 zero, move decimal 1 place to the right		
2	Add 2 zeros, move decimal 2 places to the right		
3	Add 3 zeros, move decimal 3 places to the right		
4	Add 4 zeros, move decimal 4 places to the right		
5	Add 5 zeros, move decimal 5 places to the right		
6	Add 6 zeros, move decimal 6 places to the right		
7	Add 7 zeros, move decimal 7 places to the right		
9	Add no zeros, move decimal 1 place to the left		

2-digit alphanumeric chip capacitors are always calculated in picofarads – the smallest unit of measurement. Unless otherwise indicated, tolerance is  $\pm$  20%.

Equivalents: 1,000,000pF (picofarads) = 1,000nF (nanofarads) =  $1\mu$ F (microfarad

## INDUCTOR VALUE AND TOLERANCE CHART



270μH <u>+</u> 2%

1st and 2nd numbers SIGNIFICANT VALUE	3rd number MULTIPLIER (number of zeros)	TOLERANCE letter code
Use as is in the order written	0 = add no zeros 1 = add 1 zero 2 = add 2 zeros 3 = add 3 zeros 4 = add 4 zeros 5 = add 5 zeros 6 = add 6 zeros 7 = add 7 zeros 8 = add 8 zeros 9 = add 9 zeros	A ±.05% B ±.1% C ±.25% D ±.5% F ±1% G ±2% H ±3% J ±5% K ±10% L ±15% M ±20%

Inductors are measured in "henries,"

There are nanohenries (nH), microhenries ( $\mu$ H), and millihenries (mH). The value of numbered inductors is calculated in microhenries, unless otherwise indicated.

Tolerance may be indicated by a letter code. When tolerance is not specified, it is assumed to be  $\pm$  20%.

Equivalents: 1,000,000nH (nanohenries) = 1,000µH (microhenries) = 1mH (millihenry)

#### DECIMALS FOR CAPACITORS AND INDUCTORS



 $.47\mu F \pm 20\%$ 

Capacitors are measured in "farads." There are picofarads (pF), nanofarads (nF), and microfarads ( $\mu$ F). Unless otherwise indicated, the default tolerance is  $\pm$  20%.

On capacitors,  $\mu$  or N is used to indicate the position of a decimal point. A  $\mu$  symbol means the measurement is calculated in microfarads. The letter N means the measurement will be in nanofarads. For example, the code 9N5 would be decoded to 9.5nF  $\pm$  20%.

Equivalents: 1,000,000pF (picofarads) = 1,000nF (nanofarads) =  $1\mu$ F (microfarad)



.79µH <u>+</u> 20%



5.5nH <u>+</u> 20%

On inductors, the letters R or K are used to indicate the position of a decimal point. For example, R37 is decoded as  $.37\mu H \pm 20\%$ .

The letter N is used to indicate the position of a decimal point when the measurement is calculated in nanohenries. For example, 9N5 is decoded as  $9.5 \text{nH} \pm 20\%$ .

Equivalents: 1,000,000nH (nanohenries) = 1,000µH (microhenries) = 1mH (millihenry)